



Acroprint Model EN With On/Off Sequencing Button Heavy Duty Electronic Numbering Machines

FOR USE IN NON-ADVANCE MODE

- Position the sequencing button on the right hand side of the machine in the “OFF” position.
- The imprint will remain the same for every document inserted.

FOR USE IN AUTOMATIC ADVANCE MODE:

- Position the sequencing button on the right hand side of the machine in the “ON” position.
- The sequence will advance automatically **AFTER** printing on a document that has been inserted.

Batch Printing

Example:

- With button in “OFF” position, print multiple documents with 04CV00001.
- Push button to “ON” position, print last document with 04CV00001 sequence automatically advances and is ready to print 04CV00002.
- Push button to “OFF” and print one or more documents with 04CV00002.

Visit www.acroprint.com/ncaoc.html for additional product information and helpful hints.

www.acroprint.com

5640 Departure Drive Raleigh, NC 27616 T: 919-872-5800 1-800-334-7190 F: 919-850-0720